


ASSEMBLY INSTRUCTIONS

TRIPLE CABIN


Rev. 0 del 01/01/2015





To assemble the single cabins that form the Triple,
special items are required.

Please follow the specific instructions to assemble
these special items.

All the special items are labeled and associated with
number and name



EXTERNAL CABINS



Use item **PS1**

Use item **PS2**

Special items for the external of the cabins

PS1

Door frame with 2 holes on the upper side






PS2

Cut door on the lower side



CENTRAL CABIN



special items for the central cabin

PS3

Cut door frame on the down side



PS4

Cut roof on the front side





Assembly instructions

Combined cabins

Rev. 0 dd. 03-04-2013

Assembly instructions for Twin cabin



1) Assembly kit for the cabins connection



ARMAL srl Unipersonale - Via Fiorentina, 109 - 50052 Certaldo (FI)
Cod. Fisc./P.Iva 03922500487 - Cap.Soc. Euro 10.400,00 i.v. - N° REA FI399675
Phone + 39 0571 665305 - Fax +39 0571 651 260 - armal@armal.biz - www.armal.biz
Società soggetta ad attività di direzione e coordinamento della Società Ylda spa



Assembly instructions

Combined cabins

Rev. 0 dd. 03-04-2013

2) connect the cabins



3) Insert the screws in the apposite holes placed in the 4 door frame corners internal side (use the plate for the lower side)



ARMAL srl Unipersonale - Via Fiorentina, 109 - 50052 Certaldo (FI)
Cod. Fisc./P.Iva 03922500487 - Cap.Soc. Euro 10.400,00 i.v. - N° REA FI399675
Phone + 39 0571 665305 - Fax +39 0571 651 260 - armal@armal.biz - www.armal.biz
Società soggetta ad attività di direzione e coordinamento della Società Ylda spa

- 4) Insert and screw the washer to the 4 screws
(use the bigger washer for the lower screw)**



-
- 5) Place the connection plate**



6) screw the connection plate to the floor using 4 self-tapping screws



**After the installation seal the Triple cabins
conjunctions to insure the inside protection**

